

S I G H T  M A R K [®]

USER MANUAL



T6 TRIPLE DUTY

Tactical Flashlight

English

ABOUT SIGHTMARK®


Sightmark offers a wide range of products that include red dot scopes, reflex sights, rangefinders, riflescopes, laser sights, night vision and award-winning flashlights and boresights. Sightmark products are inspired by military and law enforcement applications. All products are designed to be the most effective weapon accessories possible.

Sightmark - MAKE YOUR MARK



T6 Triple Duty Tactical Flashlight 1- 8

ENGLISH





FEATURES:

- 600 Lumen Cree LED
- 2-stage push on/off button or pressure pad operation
- Aircraft grade aluminum construction
- 3-prong glass breaking bezel
- Waterproof and dustproof
- Type II Mil-spec anodizing


INCLUDES:

- Weapons mount
- Pressure pad
- Lanyard
- Push button cap
- Belt clip



TECHNICAL SPECIFICATIONS

Bulb type	CREE T6 LED
Bezel diameter, mm	32
Output max	600
Battery life	600 lumens-1 hour Drops to 200 Lumens -5 hours
Battery type	2xCR123A
Finish	Type II Mil-spec anodizing
Waterproof rating	IP67-dustproof/waterproof
Dimensions, mm	137.3x35x35
Weight w/ batteries, oz	5.9



DIAGRAM

1. Bezel head cap
2. Bulb assembly
3. Flashlight body
4. Battery compartment
5. Battery cap / push button switch
6. Pressure switch
7. Bolt / pocket clip
8. Offset mount



BATTERIES

The Sightmark T6 Triple Duty Flashlight is powered by two CR123A batteries.

To insert or remove the battery:

- 1) Rotate the battery cap/switch (5/6) counterclockwise until it separates from the flashlight body (3).
- 2) Insert both CR123A rechargeable batteries into the battery compartment (4), with the positive end first, as shown on the battery.
- 3) Replace the battery cap/switch (5/6) onto the flashlight body (3). To tighten, rotate the cap/switch clockwise until fixed firmly. Do not over tighten.

SWITCH OPERATION

After inserting the batteries, install the desired battery cap/switch.

Push button switch (5):

- 1) For momentary operation, press lightly on the rubber button on the back of the switch.
- 2) For permanent operation, press the rubber button until you hear or feel a "click" then release.
- 3) To turn the flashlight off, press the rubber button a second time until you hear or feel a "click", then release.

Pressure switch:

- 1) For momentary operation, press firmly on the pressure pad.
- 2) To turn the flashlight off, release the pressure on the pressure pad.

MOUNTING

The Sightmark T6 Triple Duty Flashlight includes an offset weapons mount. Before mounting the flashlight onto your firearm, be sure the firearm is unloaded and safe to handle.

To mount:

- 1) Using the Allen wrench, loosen the two screws on the weapon mount's (8) ring.
- 2) Remove the top part of the ring mount and insert the flashlight into the mount's base ring.
- 3) Attach the top part of the ring mount and tighten the ring screws. Do not over tighten.
- 4) Next, loosen the mounting bolt on the weapon mount using the provided Allen wrench.
- 5) Position the weapon mount onto your firearm's base.



STORAGE

Make sure that your Sightmark tactical flashlight is securely attached to your firearm before storing, and be sure the unit is turned off. Remove the battery if the flashlight will be stored for an extended period of time.

MAINTENANCE

The flashlights may be cleaned using a soft cloth and water, or a gun cleaning solvent, when exposed to dirt, dust, or other residue. Clean the lens using a soft cloth dipped in water or denatured alcohol. To clean residue from contacts, use a cotton swab dipped in denature alcohol. Maintain threads and O-rings by applying a silicon-based grease to those areas.



WARNING

Before handling the tactical flashlights, read and understand the contents of your firearm's manual, and the Sightmark tactical flashlight manual. Follow all standard safety precautions and procedures during firearm operation, even when the flashlight is not in use.

- NEVER point the flashlight directly at, or into, an eye. This may cause damage to the eye, or blindness. The flashlights produce enough light to identify an individual without direct illumination to the face.
- Avoid looking directly into the flashlight's beam.
- Avoid shining the flashlight into mirrors or other reflective surfaces.
- Avoid hitting or dropping the unit.
- ALWAYS check that the chamber of your weapon is clear before mounting or dismounting the flashlight.
- ALWAYS remove the flashlight when cleaning, or performing other maintenance on your firearm.
- The flashlight should be tested during periods of non-use to make sure it is still operating properly.
- NEVER place the flashlight bulb side down on a surface while it is on. The bulb generates heat that can damage the unit or the surface it is on.

Failure to follow standard firearm safety precautions and procedures, as well as the above warnings, is dangerous and may result in serious injury, damage to property, or death.

TROUBLESHOOTING

Never ship back a product without getting proper authorization beforehand. Doing so could result in losing the product due to a multitude of reasons, i.e. sending it to the wrong address and other problems associated with unexpected packages.

1. If the unit is not turning on, check the polarity of the battery and that the batteries are charged.
2. If the unit turns off during firing, check the battery cap is completely attached and a firm contact is made between the spring and battery.

SIGHTMARK WARRANTY

Please visit www.sightmark.com for warranty details and information.

S I G H T  M A R K [®]

www.sightmark.com